

ZOOMER 50 FI STAINLESS EXHAUST PIPE INSTRUCTION MANUAL



1. Put the rubber ring into ring.




2. Put the new included gasket on the cylinder studs.



3. Install the front pipe.



4. Screw on the manifold nuts with hand.




5. Install motor bracket and motor with bolts and screw on.



6. Install end pipe into front pipe.



7. Screw on ring with hand.



8. Tighten down all screws with a socket after finishing installing step 2. to 7.



9. Finish!