

培林式(原廠型)加油座安裝說明

BEARING ORIGINAL TYPE ALUMINUM ACCELERATOR POST INSTALLING MANUAL



諸元表

握把左、右邊各一

PARTS LIST:

1. LEFT GRIP*1 RIGHT GRIP*1



由於每支車手的烤漆厚薄不一，若在安裝此產品時不好安裝，請用砂紙將車手上的漆磨掉一些即可安裝。

BASICALLY COATING THICKNESS OF EVERY HANDLEBAR IS DIFFERENT. AS YOU INSTALL THIS PARTS , YOU CAN USE SANDPAPER TO ERASE SOME COATING AND THEN YOU CAN INSTALL IT EASILY.