INSTALLING MANUAL FOR CNC SWITCH FOR CUXI 100

- 1. CNC SWITCH IS THE UNIVERSAL PARTS WHICH ONLY CAN BE INSTALLED ON THE CARBURETOR TYPE SCOOTERS.
- 2. IF FI TYPE SCOOTER, NO NEEDS TO INSTALL THIS ACCESSORY

ACCESSORY

HEXAGON SOCKET

COUNTERSUNK-HEAD

SCREW M4*0.7*12mm*1pc

1ST PHOTO



THE POSITION OF LOCK

2ND PHOTO



FINISHED PHOTO



USE LOCKTIE TO FASTEN SCREW

INSTALLING MANUAL FOR CNC SWITCH FOR CUXI 100

 CNC SWITCH IS THE UNIVERSAL PARTS WHICH ONLY CAN BE INSTALLED ON THE CARBURETOR TYPE SCOOTERS.
IF FI TYPE SCOOTER, NO NEEDS TO INSTALL THIS ACCESSORY

1ST PHOTO



HEXAGON SOCKET

COUNTERSUNK-HEAD

SCREW M4*0.7*12mm*1pc



THE POSITION OF LOCK

2ND PHOTO



USE LOCKTIE TO FASTEN SCREW

FINISHED PHOTO

