

預載調整器安裝說明

INSTALLING MANUAL FOR FRONT FORKS PRELOAD ADJUSTER

- 步驟一、 拆除原本前叉上蓋螺栓

STEP1: Take off original top cover bolt of front forks.



- 步驟二、 將預載調整器逆時針歸零

STEP2: Turn counter clockwise to zero reset preload adjuster.



- 步驟三、 將預載調整器安裝上前叉

STEP3: Install preload adjuster on front forks.



- 步驟四、 依照個人需求順時針旋轉所需增加之彈簧力 (0~10圈)

STEP4: Turn clockwise to add spring force (Roll 0~10) by personal requirement.



* 建議值：單人騎乘 (0~5圈) 雙人騎乘(6~10圈)
Adjusting suggest: 1person riding (Roll 0~5); 2 people riding (Roll 6~10)